



Software module ATMS CORE “Lean”

ATMS CORE module “Lean”

Single-station version without master data maintenance

The basic requirement is the license module ATMS CORE “Lean License”

The basic requirement is a Master System with ATMS CORE “Server” or ATMS CORE “Cloud”

- Modern, uniform user interface color design
- Management of items in the "new" state
- Product group management
- Login by entering a number combination
- Interface to standard 2D barcode reader for registration (a special 2D barcode reader is also required)
- Control for certain Toolbase systems (AR-18L, AR-18S, AW-6L, EB-X)
- Master data maintenance, evaluations and ordering via Master System (with ATMS CORE Modul Server or Cloud)

Part of Toolbase Control Lean Systems.